



IPS Multi-Display Clock

HOW TO SYNC TIME WITH WIFI

1. Select your time zone and click apply to set the time. Time on the clock will be adjusted synchronously.



2. Enter WIFI INFO for NTP (Network Timing Protocol)



Once WIFI is connected, the clock will synchronize the time every other hour and keep your time accurate. Please note that due to network delay, it is normal if time is one or two seconds slower.

